

PrepPDF

Pass Your Next Certification Exam Fast!

Everything you need to prepare, learn & pass your certification exam easily.

365 days free updates. First attempt guaranteed success.

Choose the version that fits your needs	PDF Version	Desktop Test Engine	Online Test Engine
Latest and Up-to-Date exam dumps with real exam questions answers.	✓	✓	✓
Get 12-Months free updates without any extra charges.	✓	✓	✓
Experience same exam environment before appearing in the certification exam.	✗	✓	✓
100% exam passing guarantee in the first attempt.	✓	✓	✓
20% discount on more than one license and 30% discount on 5+ license purchases.	✗	✓	✓
100% secure purchase on SSL.	✓	✓	✓
Completely private purchase without sharing your personal info with anyone.	✓	✓	✓

<http://www.preppdf.com>

Reasonable study tool and effective study materials - PrepPDF

Exam : 920-216

Title : Multiservice Switch
7000/15000/20000 Operations and
Maintenance

Vendors : Nortel

Version : DEMO

NO.1 A partial listing of the attributes of the provisioning component appears as follows:

committedFileName: startup.full.001 currentViewFileName: startup.full.003

lastUsedFileName:

startup.full.005 editViewName: startup.full.005 Which view will be used if the switch resets or restarts?

- A. startup.full
- B. startup.full.001
- C. startup.full.003
- D. startup.full.005

Answer: B

NO.2 Which command is used to find the application versions that are compatible with base_CD01A?

- A. l sw av/base_CD01A
- B. d sw av/base_CD01A
- C. d sw compatibleListing
- D. d sw av/base_CD01A feat/*

Answer: B

NO.3 Which verb is used to change an attribute value?

- A. set
- B. add
- C. load
- D. reset

Answer: A

NO.4 Which two actions does the Multiservice Switch 7000/15000/20000 startup utility enable you to do?

(Choose two.)

- A. Configure a spare Control Processor.
- B. Power-up the Multiservice Switch node.
- C. Reset node to Function Processor only software.
- D. Define the method used for Preside MDM connectivity.

Answer: AD

NO.5 Which condition is true when performing a card test?

- A. The card being tested needs to be locked.
- B. The ports on the card being tested need to be locked.

- C. The target card's test component needs to be started first.
- D. A card can be both running a test and act as a target for another card being tested.

Answer: D

NO.6 Which command is used to display the values of the "committedfilename", "currentviewfilename", and "editviewname" attributes?

- A. lock prov
- B. help prov
- C. list prov
- D. display prov

Answer: D

NO.7 Which type of view saves the provisioning of a single component and all of its subcomponents and associated provisionable attributes on a Multiservice Switch 7000/15000/20000?

- A. delta
- B. partial
- C. portable
- D. committed

Answer: B

NO.8 The provisioning view startup.full.005 has been loaded into the edit view. Several components were added and attributes changed. The view was then checked, activated and confirmed. What is the value of the "editviewname" attribute?

- A. none
- B. defined .005
- C. startup.full.005
- D. startup.full.006

Answer: A

NO.9 Which provisioning view is loaded when a Multiservice Switch node resets?

- A. edit view
- B. current view
- C. last Used view
- D. committed view

Answer: D

NO.10 Which verb can only be used in the provisioning mode?

- A. list
- B. lock
- C. help
- D. delete

Answer: D

NO.11 Which command allows the output of alarms to the terminal to be disabled, while being logged into a

Multiservice Switch 7000/15000/20000 node using telnet?

- A. set col/alarm sp spooling off
- B. set col/alarm sp spooling =off
- C. set NMIS Telnet session/ datastreams ala
- D. set NMIS Telnet session/ datastreams ~ala

Answer: D

NO.12 What is the maximum time allocated to confirm provisioning after activation?

- A. 5 minutes
- B. 10 minutes
- C. 20 minutes
- D. 30 minutes

Answer: C

NO.13 Which attribute, under a DS3 port component, associates it with the Atmif service?

- A. lineInterface
- B. framerName
- C. interfaceName
- D. applicationFramerName

Answer: D

NO.14 Which type of view has a base view on a Multiservice Switch 7000/15000/20000?

- A. delta
- B. partial
- C. portable
- D. committed

Answer: A

NO.15 Which two components can be provisioned directly under an LP component? (Choose two.)

- A. e0
- B. oc3
- C. ds3
- D. sonet

Answer: CD

NO.16 Which two provisioning conditions must apply to configure one-for-one sparing between two function processors on a Multiservice Switch 7480? (Choose two.)

- A. Both cards are provisioned as the same card type.
- B. Both cards are referenced under one logical processor.
- C. Both cards have individual logical processors that reference each other.
- D. An equal number of port components are provisioned under the Shelf Card components.

Answer: AB

NO.17 Which command is used to show all provisioning views stored on the Control Processor disk?

- A. display view/*
- B. list prov view/*
- C. list view/* prov
- D. display view/* prov

Answer: B

NO.18 A 4-port DS1 card is in slot 6 of a Multiservice Switch 7000. A trunking service runs on Port 3 of the

DS1 card. What is the recommended instance value for this trunk?

- A. Trk/36
- B. Trk/43
- C. Trk/63
- D. Trk/DS16

Answer: C

NO.19 Which provisioning view is active and running on the Multiservice Switch?

- A. edit view
- B. current view

- C. last used view
- D. committed view

Answer: B

NO.20 Which selection is the instance range for a Logical Processor on a Multiservice Switch 7480?

- A. 0 to 4
- B. 0 to 15
- C. 1 to 15
- D. 0 to 16

Answer: B